

# HEAVY DUTY LINE MARKING TAPE

Long lasting, 1mm thick floor marking tape for heavy wear areas



### AREAS OF USE

- Marking out walkways, loading areas or hazardous areas

### FEATURES

- Quick and simple to apply by hand
- Hard wearing and durable
- Made from 1mm thick PVC with chamfered edges to reduce scuffing and lifting
- High performance self adhesive backing
- The adhesive is coated edge to edge to reduce any edge lift
- Easy to clean

### DESCRIPTION

Watco Heavy Duty Line Marking Tape is a special high performance tape for heavy wear areas. Ultra durable when compared to conventional floor tapes. Made from 1mm thick robust PVC with a high performance self adhesive backing and chamfered edges to prevent tripping. The photoluminescent grade is off-white and translucent in the light. Once the lights go off, it glows for up to 30 minutes with a yellow/green colour, showing safe exit routes or hazardous areas.

### SPECIFICATION

Composition	PVC.	Length	30m
Primer Required	No.	Widths	50mm, 70mm and 100mm.
Usage Interior/ Exterior	Interior & exterior.	Storage	Store in cool, dry conditions away from direct sunlight.
Application	Self adhesive.		

Samples are available on request.  
While great care is taken with the colour samples shown, no guarantee can be given that they represent exactly the colours offered.

### COLOURS

	Hazard		Black
	Orange		Red
	White		Green
	Yellow		Photoluminescent
	Blue		Yellow Fluorescent
	Red/White		

### PREPARATION & APPLICATION

#### SURFACE PREPARATION

Apply to clean, smooth, dry surfaces such as painted or varnished wood, concrete, metal, tiles, and Terrazzo.

#### APPLICATION

Avoid application at temperatures below 10°C. Low temperatures can reduce adhesion.

Peel back the backing strip approximately 50mm to reveal the adhesive layer. Avoid removing too much of the backing strip, but slowly keep peeling it back whilst firming the product into place. Firming down by hand or foot pressure is generally sufficient. Avoid stretching the tapes during application.

#### ADHESION

Although the product can be walked on virtually straight away, the adhesive can take 24 hours to set fully. Immediately after placing the item onto the substrate, it can be peeled off reasonably easily for repositioning if necessary. Avoid removing the tape to allow the adhesive to cure.

Please allow the adhesive to set for up to 24 hours, especially if using in heavily trafficked or hazardous areas.



[WATCO.CO.UK](http://WATCO.CO.UK)