

Tack Coat

EPOXY RESIN ADHESIVE PRIMER

[®]
watco

The UK's leading direct
supplier of industrial
strength flooring products



Watco Tack Coat is an epoxy resin adhesive primer for use prior to screeding with Watco Concrex[®] or Watco Concrex[®] Vertical.

Also available
from Watco

Floor Paints & Coatings

Dustproofers & Sealers

Line Marking

Flooring

Anti Slip Coatings

Anti Slip Products

Floor Repair Materials

Screeds

Preparation Materials

Masonry Repair Materials

Wall Coatings

Exterior Products

Traffic Control

Metal Coatings

Roofing

Watco UK Limited
Eastgate Court,
195-205 High Street,
Guildford, Surrey GU1 3AW, UK
Tel: 01483 418 418
Fax: 01483 42 8888
www.watco.co.uk
E-mail: sales@watco.co.uk

Watco Tack Coat

AVAILABILITY

Tack Coat is available in 1m² and 6m² packs.

STORAGE

Store Watco Tack Coat for 8 hours prior to use at 15°C - 20°C to ensure maximum pot life when mixed.

SURFACE PREPARATION

Concrete

Ensure surface is clean and free of all loose material. Watco Tack Coat may be applied over existing paint but all poorly bonded paint must be removed and well bonded paint roughened to provide a key.

Metal

Remove any loose or flaking material and rust by wire brushing or disc grinding. Oil or grease should be removed with Watco Bio-D and the metal allowed to dry. Watco Tack Coat should be applied immediately after cleaning and drying.

MIXING

Pour the contents of the smaller tin into the larger tin and mix thoroughly with a wide bladed tool. When using the 6m² pack decant into a shallow tray. Do not leave mixed components in the tin - the product will quickly become unusable and the tin become hot. Use immediately.

POT LIFE

20 minutes maximum at 20°C when decanted into a shallow tray. Higher temperatures will reduce the pot life.

APPLICATION

Apply sparingly by roller or brush and allow to become tacky. Overlaying must be completed while the Watco Tack Coat is still tacky.

CURING TIME

Watco Tack Coat should be sufficiently tacky to overlay after approximately 60 minutes at 15°C - 20°C, but this will be extended to 3 hours at 5°C.

Overlaying must be completed before the Watco Tack Coat cures. If the Watco Tack Coat is allowed to harden a fresh pack of Watco Tack Coat must be brushed over the surface, if possible within 24 hours.

SAFETY

Gloves are recommended. Food products must be removed from the area during application and cure. Material Safety Data Sheets are available.

ORDERING

All products are available direct from Watco UK Limited in the UK and through agents worldwide. All Watco products are sold subject to the Company's Standard Conditions of Sale.

The Company and its representatives are often asked to comment on potential uses of Watco products which differ from those described in the Company's data sheets. Whilst in such cases the Company and its representatives will always try to offer helpful and constructive advice, the Company cannot be held responsible for the results of such uses unless they are specifically confirmed in writing by Watco.

watco®

© Watco UK Ltd March 2016

Quality Certified



Designed, manufactured and supplied under an ISO 9001 quality management system